



# IFMIF-DONES related activities at Lithuanian Energy Institute



Andrius Tidikas, Gediminas Stankūnas, Simona Breidokaitė, Benjaminas Togobicki, Dilmurod Tuymurodov  
and WPENS contributors  
Lithuanian Energy Institute



This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement number 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.




- Introduction to the Lithium loop cell
- Simplified model
  - Key assumptions of source term modelling
- Detailed model
  - Extended assessment

- High-intensity deuteron beam (125 mA, 40 MeV) interacts with lithium
- **Key reactions:**
  - $7\text{Li}(d,2n)7\text{Be}$  &  $6\text{Li}(d,n)7\text{Be} \rightarrow$  **Beryllium-7** (dominant radioisotope)
  - Neutron activation of **SS316L & EUROFER**  $\rightarrow$  Activated Corrosion Products (ACPs)
- **Key considerations:**
  - Dissolution
  - Deposition
  - Trapping and purification efficiency






## Simplified Lithium loop model

- **Lithium Loop System Components:**
  - **Cold Leg (CL):** Outflow from heat exchanger
  - **Cold Trap (CT):** Mesh filter for Be-7 and impurities
  - **Heat Exchanger (HX):** Maintains lithium temperature and impurity removal
- **Key Assumptions:**
  - **Be-7 uniformly dissolved** in lithium at 3.26E-05 appm
  - **Flow regime** 300°C in the cold leg, and a 2% flow rate
  - **Two corrosion models:**
    - Basic: **2  $\mu\text{m}/\text{year}$**  corrosion for all components
    - Reduced: **0.4  $\mu\text{m}/\text{year}$**  for CL, HX, hot leg; **0.133  $\mu\text{m}/\text{year}$**  for quench tank
  - Gamma spectra calculated at 0s, 1h, 1d, 1 week decay




FISPACT-2 code was utilized for the spectral and decay calculations



- **Gamma Spectra Breakdown:**
  - **Be-7:** Peak at **477.6 keV**, dominates activity in cold trap
  - **ACPs:**
    - **HX & CL:** Co-58, Co-60, Mn-54, Fe-55...
    - **Cold trap:** 3 orders of magnitude higher Be-7 activity
  - Spectra divided into **18 energy groups** (0–5 MeV)
- **Key difference:**
  - Reduced corrosion model shows **~5x lower cobalt levels**



- **MCNP 6 Simulations:**
  - Biological dose rates using ANSI/ANS 6.1.1-1977 conversion
  - $2 \times 10^9$  particle histories per run
  - tally planes used for spatial dose mapping
- **Dose Rate Findings:**
  - General range: **1–100 mSv/h** (LLC)
  - Peak values near sources: **Up to 10 Sv/h and more** (Cold Trap)
  - Cold Leg causes **radiation streaming through the ceiling**




- **Cooling for 1 week:**
  - Be-7 activity reduced by **~10%**
  - ACPs (Co-58, Mn-54, Fe-55) decrease by **~20%**
- **Reduced Corrosion Model Effects:**
  - Minimal impact on dose rates
  - Cobalt isotopes lower in lithium but remain significant
- **10-Year Radionuclide Trends:**
  - Co-60 dominates dose rates
  - Fe-55 dominates activity
  - No new significant radionuclides form during decay
  - Differences in corrosion models:
    - **EUROFER vs. SS316L** affects cobalt & chromium levels
    - **Cobalt moderately soluble** → higher presence in basic model
    - **Chromium less soluble** → minor impact




## Lithium Dump Tanks (DT) & Electro-Magnetic Pumps (EMP)

- **Lithium Dump Tanks (DT) Functions:**
  - Store and melt lithium during system startup
  - Collect lithium during shutdowns (normal or emergency)
  - Purify lithium via nitrogen trapping
- **Updated Design:** Two separate tanks
  - **DT1:** Lithium storage and melting
  - **DT2:** Lithium purification with nitrogen trapping
- **Electro-Magnetic Pumps (EMP):**
  - Ensure continuous lithium flow
  - Provide redundancy for safety compliance
- **CAD to MCNP:**
  - McCAD was used in Salome environment.









- **Radiation Sources in Lithium System:**
  - Be-7
  - ACPs
- **Shielding Approaches:**
  - **DT shielding:** 100 cm cover of standard concrete, 50 cm separation wall
- **Expected results:**
  - **Room R016 dose rates:** 1–100 mSv/h (up to 20 days after shutdown)
  - **Shielded DT reduces dose to  $\mu\text{Sv/h}$  levels**





- **Variance Reduction with ADVANTG:**
  - Improves accuracy near leakage points
  - Reduces uncertainties by 10%
- **Assumptions:**
  - Beam off scenario (lithium in DT, traces in the pipes)
  - Beam on scenario (lithium circulated in pipes, traces of lithium in DT)
  - Standard vs. heavy concrete
- **Lithium traces were not considered!**



- **Case 1: Ordinary Concrete Shielding (Beam-Off)**
  - DT pit with **1m concrete cover + 50cm separation wall**
  - Dose rate outside shielding: **10  $\mu\text{Sv/h}$**
- **Case 2: Heavy Concrete Shielding (Beam-Off)**
  - Same geometry
  - Dose rate reduced to **1  $\mu\text{Sv/h}$**



- **Case 3: Beam-On with Lithium in Piping**
  - Dose rates: Up to  $10^4$   $\mu\text{Sv/h}$  inside LLC room
- **External Exposure:**
  - Corridor C002: 10  $\mu\text{Sv/h}$
  - Cold Trap Cell (R009-1): 1  $\mu\text{Sv/h}$
- **Shielding Effectiveness:**
  - 1m of concrete shields **most of LLC room**
  - Heavy concrete reduces external dose by **10x**





## Key Findings:

- Reduced corrosion model has **limited impact on dose reduction**
- Beam-off dose rates are manageable with shielding
- Beam-on operation causes high radiation fields ( $10^4$   $\mu\text{Sv/h}$ )
- Heavy concrete is around 10 times greater in mitigating dose rates outside DT
- Radiation Levels in adjacent rooms

## Things to consider

- **ACP and Be-7 trapping optimization**
- **Improved shielding designs**
- **Refinement of corrosion models**

